



NB: There are some other internal fittings which for simplicity are not shown on this drawing. If you are constructing your own building it is important to line the cubicle with a good quality board not less than 12mm thick in order to fix these without difficulty.

**NatSol**  
 THE COMPOST TOILET SPECIALISTS

Grab Rail Wooden Building

Drwg. No. FA 011 mw 1  
 Date: 5.12.11 Scale: 1:20  
 Drawn: NJG altered mw  
 NatSol Ltd  
 Tel: 01686 412653  
 www.natsol.co.uk